

# VIA® USB 3.0 Driver Package Release Notes

2016-11-08

---

[Support Platforms](#)

[Component version inside this package](#)

[Notices](#)

[Update of this Release](#)

[Installation and Uninstall](#)

[Known Issues](#)

[Limitations](#)

[Revision History](#)

[DISCLAIMER](#)

---

## Support Platforms

### Hardware:

VIA XHCI Host Controller

### Operating System:

Microsoft Windows® 8.1 X86/X64, Windows® 8 X86/X64, Windows® 7 X86/X64, Windows® Vista X86/X64, Windows® XP X86/X64

[/Back to top](#)

---

## Component version inside this package

Component	Version
VIA USB 3.0 Driver for Windows 8/8.1	Port Driver (Xhcdrv.sys): 6.1.7600.4402 Hub Driver (Viahub3.sys): 6.1.7600.4402
VIA USB 3.0 Driver for Windows 7	Port Driver (Xhcdrv.sys): 6.1.7600.4402 Hub Driver (Viahub3.sys): 6.1.7600.4402
VIA USB 3.0 Driver for Windows Vista	Port Driver (Xhcdrv.sys): 6.1.7600.4402 Hub Driver (Viahub3.sys): 6.1.7600.4402
VIA USB 3.0 Driver for Windows XP	Port Driver (Xhcdrv.sys): 6.1.7600.4402 Hub Driver (Viahub3.sys): 6.1.7600.4402
VIA USB 3.0 UASP Client Driver	6.1.7600.4002
VIA USB 3.0 UASP Transfer Mode Utility	1.0.0.15

[Back to top](#)

---

## Notices

1. In this driver package, it contains both the drivers for USB 3.0 host controller and UASP storage device driver.
2. Please update your VIA XHCI host controller PCIe Card with latest version of firmware which can support UASP before install this driver.
3. This UASP driver needs to work together with the "VIA USB 3.0 Speeder" utility.

[Back to top](#)

---

## Update of this Release

1. Fix setup package issue of WinXP x86.

[Back to top](#)

---

## Installation and Uninstall

1. Please update your VIA XHCI Host Controller PCIe Card to latest version of firmware before you install this driver.
2. Please use the setup program to install/uninstall the driver for XHCI host controller and its root hub device.
3. Following is the instruction for silent mode driver installation/removal.

Command line	Execution
VIA_XHCI_Driver_V4.40E.exe /silent	Silent Installation
VIA_XHCI_Driver_V4.40E.exe /verysilent	Very Silent Installation(system will reboot automatically)
VIA_XHCI_Driver_V4.40E.exe /verysilent /norestart	Very Silent Installation(system won't reboot)

4. Manual Install & Manual Un-Install

### 4.a Manual Install:

Step 1. Select "VIA USB eXtensible Host Controller" in the Device Manager. Choose the Driver Tab. Click the "Update Driver" icon.

Select "Xhcdrv.sys" which locates in the driver folder.

Step 2. Select "VIA USB 3 Root Hub" in the Device Manager. Choose the Driver Tab. Click the "Update Driver" icon.

Select "Viahub3.sys" which locates in the driver folder.

Step 3. Select "VIA USB 2 Hub" in the Device Manager. Choose the Driver Tab. Click the "Update Driver" icon.

Select "Viahub3.sys" which locates in the driver folder.

Step 4. Restart your system.

#### 4.b Manual Un-Install:

Step 1. Select "VIA USB 2 Hub" in the Device Manager. Choose the Driver Tab. Click the "Uninstall" icon.

Select OK for "Confirm Device Uninstall".

Step 2. Select "VIA USB 3 Root Hub" in the Device Manager. Choose the Driver Tab. Click the "Uninstall" icon.

Select OK for "Confirm Device Uninstall".

Step 3. Select "VIA USB eXtensible Host Controller" in the Device Manager. Choose the Driver Tab. Click the "Uninstall" icon.

Select OK for "Confirm Device Uninstall".

Step 4. Restart your system.

[Back to top](#)

---

## Known Issues

1. Following is a list of USB devices which has compatible issue with this driver.  
N/A

[Back to top](#)

---

## Limitations

[Back to top](#)

---

## Revision History

Version	Release Date	Comments
V1.00 A (WHQL)	2010-12-08	VIA Windows 7 XHCI Driver (Logo'd)
V1.10 A (WHQL)	2010-12-31	VIA Windows 7 XHCI Driver (Logo'd)
V1.20 A (WHQL)	2011-01-12	VIA Windows 7 and Windows XP XHCI Driver (Logo'd)
V1.30 A (WHQL)	2011-03-02	VIA Windows 7 XHCI Driver (Logo'd)
V1.40 A (WHQL)	2011-03-11	VIA Windows 7, Vista and XP XHCI Driver (Logo'd)
V1.41 A (WHQL)	2011-03-21	Update WinXP Logo'd driver
V1.50 A (WHQL)	2011-05-25	VIA Windows 7 XHCI Driver (Logo'd)
V1.60 A (WHQL)	2011-05-31	VIA Windows 7 XHCI Driver (Logo'd)
V1.60 B (WHQL)	2011-06-21	VIA Windows 7, XP XHCI Driver (Logo'd)

V1.70 A (WHQL)	2011-09-06	VIA Windows 7 XHCI Driver (Logo'd)
V1.80 C (WHQL)	2012-01-06	VIA Windows 7 and Windows XP XHCI Driver (Logo'd)
V1.90 A (WHQL)	2012-02-08	VIA Windows 7 and Windows XP XHCI Driver (Logo'd)
V2.10 A (WHQL)	2013-01-14	WHQL Driver (Win8, Win7, Vista, XP: V2.108), Non-WHQL (Client:V4.00Beta1)
V2.10 B (WHQL)	2013-01-21	WHQL Driver (Win8, Win7, Vista, XP: V2.108; Client:V4.002)
V2.10 C (WHQL)	2013-01-24	WHQL Driver (Win8, Win7, Vista, XP: V2.108; Client:V4.002)
V2.10 D (WHQL)	2013-02-21	WHQL Driver (Win8, Win7, Vista, XP: V2.108; Client:V4.002)
V2.10 E (WHQL)	2013-04-11	●WHQL Driver (Win8, Win7, Vista, XP: V2.108; Client:V4.002)
V2.10 F (WHQL)	2013-05-08	●WHQL Driver (Win8, Win7, Vista, XP: V2.108; Client:V4.002)
V2.10 G (WHQL)	2013-06-03	●WHQL Driver (Win8, Win7, Vista, XP: V2.108; Client:V4.002)
V4.10 A (WHQL)	2013-07-31	●WHQL Driver (Win8, Win7, Win XP: V4.10Beta4; Client:V4.002)
V4.20 B (WHQL)	2013-09-03	●WHQL Driver (Win8.1, Win8, Win7, Win XP: V4.201; Client:V4.002)
V4.30 A (WHQL)	2013-11-12	●WHQL Driver (Win8.1, Win8, Win7: V4.301; Client:V4.002)
V4.40 D (WHQL)	2014-01-21	●WHQL Driver (Win8.1, Win8, Win7, Vista, XP: V4.402; Client:V4.002)
V4.40 E (WHQL)	2016-11-08	●WHQL Driver (Win8.1, Win8, Win7, Vista, XP: V4.402; Client:V4.002)

[Back to top](#)

## DISCLAIMER

Information in this document is provided in connection with VIA USB 3.0 driver package. VIA Technologies assumes no responsibility for any errors in this document. Any part of document MUST NOT be reproduced, transmitted, or translated into any language, or in any form without the prior written permission of VIA Technologies Inc.

VIA may make changes to specifications and product descriptions at any time, without notice.

Copyright © VIA Technologies, Inc. 2009-2013

[Back to top](#)

All copyrights are reserved by VIA Technologies, Inc. <http://www.via.com.tw/en>